

## Microphone Cable Cleat Mounting Instructions

1. Using a 13/64" drill bit, drill two holes for the screws to mount the cable cleat as follows:
  - Drill the first hole 10" in from the front of the cart and 2-1/4" to the right of the PC security tray.
  - Drill the second hole 11-11/16" in from the front of the cart and 2-1/4" to the right of the PC security tray.

**Note:** The mounting holes for the cleat are 1-11/16" on center.

2. Using the screws (2 each 10-24 x 2" machine screws) and Keps nuts (2 each 10-24); mount the cleat to the cart.

